

■定格総荷重表

(単位: ton)

アウトリガ使用時								
作業半径 (m)	最大張出(全周)				中間張出 4.7m(側方)			
	8.4mブーム	14.5mブーム	20.6mブーム	26.7mブーム	8.4mブーム	14.5mブーム	20.6mブーム	26.7mブーム
2.5	20.00	16.00			20.00	16.00		
3.0	20.00	16.00			20.00	16.00		
3.5	20.00	16.00	9.00		20.00	16.00	9.00	
4.0	18.50	15.50	9.00		18.50	15.50	9.00	
4.5	16.50	14.20	9.00	6.80	16.50	14.20	9.00	6.80
5.0	15.00	13.10	9.00	6.80	15.00	13.10	9.00	6.80
5.5	13.70	12.10	9.00	6.80	12.50	12.10	9.00	6.80
6.0	12.50	11.20	9.00	6.80	10.60	10.20	9.00	6.80
6.5	11.50	10.40	8.50	6.80	9.00	8.75	8.50	6.80
7.0		9.70	8.00	6.80		7.60	8.00	6.80
8.0		8.45	7.10	6.10		5.80	6.45	6.10
9.0		6.70	6.40	5.50		4.65	5.20	5.50
10.0		5.45	5.80	5.00		3.80	4.30	4.55
12.0		3.80	4.30	4.20		2.55	3.05	3.30
14.0			3.20	3.45			2.20	2.40
16.0			2.40	2.65			1.60	1.80
18.0			1.85	2.10			1.15	1.35
20.0				1.60				1.00
22.0				1.25				0.70
24.0				0.95				0.50
25.0				0.80				

(単位: ton)

作業半径 (m)	中間張出 3.6m(側方)				最小時(ハーカルのみ)但しH型のみ(側方)			
	8.4mブーム	14.5mブーム	20.6mブーム	26.7mブーム	8.4mブーム	14.5mブーム	20.6mブーム	26.7mブーム
2.5	20.00	16.00			10.50	9.50		
3.0	20.00	16.00			10.50	9.50	6.50	
3.5	18.80	16.00	9.00		8.20	7.60	6.50	
4.0	14.50	13.60	9.00		6.50	6.10	6.50	4.00
4.5	11.50	11.10	9.00	6.80	5.35	4.90	5.50	4.00
5.0	9.50	9.10	9.00	6.80	4.45	4.10	4.60	4.00
5.5	8.00	7.65	8.10	6.80	3.75	3.40	3.90	4.00
6.0	6.90	6.50	7.00	6.80	3.20	2.85	3.30	3.50
6.5	6.00	5.60	6.15	6.30	2.70	2.40	2.85	3.05
7.0		4.85	5.40	5.60		2.05	2.50	2.65
8.0		3.75	4.25	4.50		1.40	1.85	2.10
9.0		2.95	3.40	3.70		0.90	1.40	1.65
10.0		2.35	2.80	3.05		0.55	1.05	1.30
11.0		1.85	2.30	2.55			0.75	1.00
12.0		1.45	1.90	2.15				0.75
13.0			1.55	1.80				
14.0			1.30	1.50				
15.0			1.05	1.25				
16.0			0.85	1.05				
17.0			0.65	0.85				
18.0			0.50	0.70				
19.0				0.55				
危険角度	—	—	—	35°	—	33°	50°	58°

■定格総荷重表

(単位: ton)

作業半径 (m)	アウトリガ不使用 定置つり							
	8.4mブーム		14.5mブーム		20.6mブーム		26.7mブーム	
	前方	全周	前方	全周	前方	全周	前方	全周
3.0	12.20	8.20	8.70	7.20				
3.5	10.70	7.20	8.70	7.00				
4.0	10.00	5.90	8.70	5.60	6.20	4.50		
4.5	8.80	4.80	8.00	4.50	6.20	4.50		
5.0	7.75	3.90	7.20	3.70	6.20	4.10	4.00	2.70
5.5	6.90	3.30	6.40	3.10	5.70	3.50	4.00	2.70
6.0	6.10	2.80	5.65	2.60	5.30	3.00	4.00	2.70
6.5	5.20	2.40	4.90	2.15	4.85	2.60	4.00	2.70
7.0			4.30	1.80	4.50	2.25	3.80	2.40
8.0			3.30	1.30	3.75	1.70	3.35	1.80
9.0			2.55	0.90	3.00	1.25	2.95	1.35
10.0			2.05	0.55	2.45	0.90	2.50	1.05
11.0			1.60		2.00	0.65	2.15	0.80
12.0			1.25		1.60		1.85	
13.0					1.30		1.55	
14.0					1.10		1.30	
15.0					0.90		1.10	
16.0					0.75		0.90	
17.0					0.60		0.75	
18.0							0.60	
19.0							0.50	
危険角度	—	—	—	33°	—	50°	35°	60°

(単位: ton)

作業半径 (m)	アウトリガ不使用時 走行つり (4 km/h以下)							
	8.4mブーム		14.5mブーム		20.6mブーム		26.7mブーム	
	前方	全周	前方	全周	前方	全周	前方	全周
3.0	8.50	6.00	6.60	5.00				
3.5	8.25	5.00	6.60	4.80		3.20		
4.0	8.00	4.30	6.60	4.10	5.00	3.20		
4.5	6.80	3.60	6.00	3.40	5.00	3.20		
5.0	5.80	3.00	5.30	2.80	5.00	3.20	2.80	1.85
5.5	5.00	2.50	4.75	2.30	4.70	2.70	2.80	1.85
6.0	4.50	2.05	4.30	1.90	4.30	2.30	2.80	1.85
6.5	4.00	1.70	3.80	1.60	3.90	2.00	2.80	1.85
7.0			3.40	1.30	3.60	1.70	2.70	1.70
8.0			2.65	0.85	3.00	1.25	2.35	1.35
9.0			2.10		2.45	0.90	2.15	1.05
10.0			1.65		2.00	0.65	2.00	0.75
11.0			1.30		1.65		1.70	
12.0			1.00		1.35		1.45	
13.0					1.10		1.20	
14.0					0.90		1.05	
15.0					0.70		0.90	
16.0					0.55		0.75	
危険角度	—	—	—	45°	25°	53°	45°	62°